

How to add energy meter Landis+Gyr E350?

Connect the Landis+Gyr E350 energy meter to the Reduxi Controller via M-Bus and the Reduxi Landis Converter.

Landis+Gyr

🔧 Landis+Gyr E350 energy meter · Reduxi Controller

🌐 M-Bus via Reduxi Landis Converter (RS485)

📄 HDLC address: last four digits of the serial number

IN THIS ARTICLE

1. Technical documentation
2. Required equipment
3. Set up the M-Bus interface on the meter
4. Connect the meter to the Reduxi Controller
 - M-Bus on the meter
 - RS485 on the converter
 - Check the converter LEDs
5. Get the serial number and the HDLC address
 - Serial number
 - HDLC address
6. Log in to the Reduxi web interface
 - Via the Reduxi app
 - Via a web browser

1 Technical documentation

Documents for this installation:

- [How to configure Landis+Gyr E350 or E450 in the MAP120 tool](#) – Reduxi guide for the M-Bus settings on the meter
- [Reduxi Converter for Landis+Gyr E350, 450 meter](#) – Connection and technical data of the Reduxi converter
- [Landis+Gyr E350 brochure \(ZCF/ZMF/ZFF100 series 2\)](#) – Manufacturer data on the meter and its M-Bus interface

2 Required equipment

You need the following components:

- ☐ Reduxi Controller or Reduxi Gateway
- ☐ Landis+Gyr E350 energy meter
- ☐ Reduxi Landis Converter RS485-M-BUS
- ☐ Cable between the converter and the controller (A, B and GND)
- ☐ Laptop or tablet with internet access to configure the device in Reduxi

3 Set up the M-Bus interface on the meter

To configure the energy meter, follow the article [How to configure Landis+Gyr E350 or E450 in the MAP120 tool](#).

4.1 Connect M-Bus on the meter

Connect M-Bus on the energy meter directly to the Reduxi Landis Converter RS485-M-BUS. The first four pins on the energy meter are available for M-Bus. You can use the first two pins from the left or the 3rd and 4th pins from the left.




M-Bus pins on the energy meter

4.2 Connect the converter to the controller

Connect the RS485 side of the Reduxi Landis Converter to the Reduxi Controller or Reduxi Gateway. Choose port one or port two:

- A → A
- B → B
- GND → GND



Connection of the converter


4.3 Check the converter LEDs

A green light and a blinking yellow light appear on the converter. If the yellow light is not blinking, the energy meter is not set from the electro-distribution and does not send data.

5 Get the serial number and the HDLC address

5.1 Get the serial number of the energy meter

Read the serial number from the energy meter. The red square in the picture shows the last four digits of the serial number. The other part of the serial number is hidden for security reasons. In your case, read the whole serial number from the energy meter.



Serial number of the energy meter

5.2 Get the physical device address (HDLC address)

The address is the last four numbers of the serial number of the energy meter.

For example, the serial number above is 3107+1000=4107.

6 Log in to the Reduxi web interface

You can open the Reduxi web interface in two ways:



Reduxi app

Via tunnel connection · works from anywhere

REMOTE



Web browser

In the local network · via IP address or `reduxi.local`

6.1 Via the Reduxi app

1

Open the app and log in

Launch the Reduxi app on your smartphone or tablet and log in with your credentials.

2

Open Reduxi devices

Tap the menu icon (three lines, top left) and select **Reduxi devices**.

3


Activate the tunnel connection

Switch on the tunnel connection and wait a moment until it is active.

4

Open the configurator

Tap **Open configurator**. The Reduxi web interface opens.



Activate the tunnel connection (step 3)

Open configurator (step 4)

6.2 Via a web browser

1

Open the login page

On a device in the same network, open a web browser and enter the controller's IP address or **`http://reduxi.local`**. You can find the controller's IP address in your router's device list or in the Reduxi app under **Reduxi devices**.


2

Log in

Username: **admin** · Password: **admin** (factory default)



Reduxi Controller login screen



Controller web interface after login

7 Add the meter to Reduxi

Use these steps to add a new meter or to edit an existing one.

7.1 Basic settings

Log in to the [Reduxi Configurator via the browser](#) (see [Point 6](#)), click **+ Add device** and enter the basic settings of the meter.

Basic settings

Device type *

Energy meter

Type *

Landis+Gyr E350

Name *

Landis+Gyr E350

Back

Next

Basic settings of the energy meter

7.2 Communication settings

Select the communication channel.

7.3 Device configuration

Choose the device configuration. You need the serial number and the physical device address (HDLC address) from [Point 5](#).

7.4 Test communication

Click **Test communication** at the bottom of the wizard. It reads the Landis+Gyr E350 once and saves nothing. If the test succeeds, click **Done**: only **Done** creates the device.



The **Test communication** button



The **Done** button

Then enter and choose the advanced settings.

8 Check the readings

8.1 Last measurements

After communication is established, check the values under **Devices – Landis+Gyr E350** in the Reduxi Configurator.

✓ Summary

Preparation (Points 1–2): Open the documentation. Prepare the controller, the converter, the cable and a laptop or tablet.

Landis+Gyr E350 (Points 3–5): Set up M-Bus on the meter. Connect the converter. Read the serial number and the HDLC address.

Add to Reduxi (Points 6–7): Log in to the Reduxi Configurator. Add the device and test communication.

Go live (Point 8): Check the last measurements under Devices.

→ Common issues

ISSUE	SOLUTION
Yellow LED on the converter is not blinking	The meter is not set from the electro-distribution and sends no data.
Test communication fails	Check the serial number and the physical device address (HDLC address) against the meter.
Open configurator does not open or stays empty	The tunnel is not active yet. Wait about 30 seconds and check that the controller is online.
Login with <code>admin</code> is rejected	The password was changed during installation. Ask the installer. The Reduxi account password does not work here.
<code>reduxi.local</code> does not load	Your device is not in the same network as the controller. Use the IP address or the tunnel connection.
Communication test fails, device shows offline	Check reachability, IP address / port / unit ID, and that the protocol is enabled on the device.

→ Related articles

Matching guides from the Reduxi knowledge base:



Reduxi Converter for Landis+Gyr E350, 450 meter

Connection and technical data of the converter.



Device setup guides

All step-by-step guides for connecting devices to the Reduxi Controller



List of supported devices

All devices that work with the Reduxi Controller



Strategies for the Reduxi Controller

Energy manager and other strategies explained