


Adding Reduxi controller to cloud

Connect the cloud and the controller for a quick overview of location power, market prices, and more. With Reduxi, cost benefits can increase by 30%.

☁ Reduxi Cloud · app.reduxi.eu 🔧 Reduxi controller

📄 Serial number or QR code



Login page of Reduxi Cloud at app.reduxi.eu

Text description of this image

IN THIS ARTICLE

1. Introduction
2. Log in and open the location settings
 - Log in to the web application
 - Choose your company
 - Choose Global Settings
 - Choose Location & Groups
3. Create the location group and the location
 - Add a location group
 - Add a location
4. Link the controller
 - Find the controller
 - Finish adding the controller
5. Summary
6. Common issues
7. Related articles

1 Introduction

The cloud is a web application used by basic users or aggregators to access key information on location power usage via the Reduxi controller. It also enables alarms, providing first-level support by sending instant location information directly to the users' email.



Benefit

Connecting cloud and controller gives a quick overview of location power, market prices, and more. With Reduxi, cost benefits can increase by 30%.


2 Log in and open the location settings

2.1 Log in to the web application

Log in at <https://app.redux.eu/>. The login page is shown in the picture at the top of this article.

2.2 Choose your company

Find the company tab and click it.



The company tab

Text description of this image

| 2.3 Choose Global Settings

Click **Global Settings** in the menu on the left.

reduxi[⚡]

Search



Amibit d.o.o




All locations



| 2.4 Choose Location & Groups

Click **Location & Groups**.




Location & Groups

Text description of this image

3 Create the location group and the location

| 3.1 Add a location group

Create a new location group and name it.




Add a location group

Text description of this image

3.2 Add a location

Create a new location and name it.




Add a location

Text description of this image

4 Link the controller

4.1 Link the controller

Click **Find Controller** and enter the serial number. If you use a phone, scan the QR code to add the controller to the cloud.



1. Enter the serial number

Text description of this image



2. Or scan the QR code

2. Text description of this image

Screenshot of the dialog Link a controller in Reduxi Cloud (dark theme, close X at the top right). Text: To link an existing controller to your profile, please enter the serial number of that controller. It is in the following format: XXXX-XXXX-XXXX-XXXX. Then: Serial

4.2 Finish adding the controller

If the controller is connected to the internet, the new location is created automatically. Devices connected to the controller are displayed as part of the new location.

For further information about the cloud, see [Reduxi Cloud](#).

✓ Summary

Introduction (Point 1): The cloud shows location power usage via the Reduxi controller and sends alarms to the users' email.

Log in and settings (Point 2): Log in at app.reduxi.eu. Choose your company, then Global Settings, then Location & Groups.

Group and location (Point 3): Create a new location group and a new location. Name both.

Link the controller (Point 4): Click Find Controller. Enter the serial number or scan the QR code. The location is created automatically when the controller is online.

→ Common issues

ISSUE	SOLUTION
The location is not created automatically	The controller must be connected to the internet (see Point 4.2).
You use a phone and cannot type the serial number	Scan the QR code instead (see Point 4.1).

→ Related articles

Matching guides from the Reduxi knowledge base:



Reduxi Cloud

Further information about the Reduxi Cloud.



Device setup guides

All step-by-step guides for connecting devices to the Reduxi Controller



Strategies for the Reduxi Controller

Energy manager and other strategies explained