

How to access to the controller using Reduxi Configurator?

Original text as published before the redesign of this article. Wording unchanged.

Archived: 28 October 2026

Reduxi controller has a built-in web interface – Reduxi Configurator. Reduxi Configurator enables easy access to the controller. In Reduxi Configurator, you can add devices for which you want to measure the electricity consumption and define the strategies to limit or distribute the electricity consumption.

Once you successfully connected the controller, use Reduxi Configurator to access the controller by following the steps:

1. Follow the instructions given in [Reduxi Controller](#) manual
2. Optionally you need to [Obtaining the IP address of the controller](#).
3. [Log in to Reduxi Configurator via browser](#).

Use admin as the username and password if requested. Note, in some controller version, the password is printed on the label