


How to update Reduxi Controller using Reduxi Configurator?

Original text as published before the redesign of this article. Wording unchanged.


Archived: 28 October 2026

This feature is available after 25.4.2023. Please follow the steps below:

1. [Log in to Reduxi Configurator - How to log in to Reduxi Configurator via browser?](#)
2. If there is any update available following screenshot will appear



3. Please click on the text "here" and wait for update to start



4. After the update process is finished, the Reduxi Configurator will automatically refresh the page where you are currently, and you can start using a new version of Reduxi Configurator

What if you have an older version of firmware which does not support updating Reduxi Controller over Reduxi Configurator? Please use [How to update Reduxi Controller over Reduxi Cloud?](#) procedure to first update the Reduxi Configurator to the latest version.