

How to connect Powerone solar power plant with Reduxi controller

Add a Power-One solar power plant to the Reduxi Controller and read its values in the Reduxi Configurator.

🔧 Power-One solar inverter · Reduxi Controller

🏠 Unit address: normally 1 🖥️ Reduxi Configurator

📄 IN THIS ARTICLE

1. Technical documentation
2. Required equipment
3. Log in to the Reduxi web interface
 - Via the Reduxi app
 - Via a web browser
4. Add the solar power plant to Reduxi
 - Basic settings
 - Communication settings
 - Test communication
5. Check the readings
6. Summary
7. Common issues
8. Related articles

1 Technical documentation

Find the instructions to connect and configure the inverter on the manufacturer web page:

- **Manufacturer web page: Power-One drivers and instructions** – Instructions to connect and configure the inverter

2 Required equipment

You need:

- ☐ Reduxi Controller
- ☐ Power-One solar inverter, connected and configured as described in the manufacturer instructions (see [Point 1](#))
- ☐ Laptop or tablet with internet access to configure the device in Reduxi

3 Log in to the Reduxi web interface

You can open the Reduxi web interface in two ways:



Reduxi app

Via tunnel connection · works from anywhere

REMOTE



Web browser

In the local network · via IP address or `reduxi.local`

3.1 Via the Reduxi app

1

Open the app and log in

Launch the Reduxi app on your smartphone or tablet and log in with your credentials.

2

Open Reduxi devices

Tap the menu icon (three lines, top left) and select **Reduxi devices**.

3


Activate the tunnel connection

Switch on the tunnel connection and wait a moment until it is active.

4

Open the configurator


Tap **Open configurator**. The Reduxi web interface opens.



Activate the tunnel connection (step 3)

Text description of this image

Screenshot of three Reduxi mobile app screens side by side, with cyan boxes and number badges 2 to 4. Left screen (dashboard, dark theme): menu icon at top left marked with a box and badge 2; 'reduxi' logo; tabs 'Real time data' (active) and 'Statistics'; price 5.79



Open configurator (step 4)

Text description of this image

Screenshot of the Reduxi mobile app showing the 'Update available' screen and the 'Tunnel connection' screen.


3.2 Via a web browser

1 Open the login page

On a device in the same network, open a web browser and enter the controller's IP address or <http://reduxi.local>. You can find the controller's IP address in your router's device list or in the Reduxi app under **Reduxi devices**.


2 Log in

Username: **admin** · Password: **admin** (factory default)



Reduxi Controller login screen

Text description of this image



Controller web interface after login

2. Text description of this image

Screenshot of the Reduxi Configurator web interface

4 Add the solar power plant to Reduxi

Use these steps to add a new device or to edit an existing one.

4.1 Basic settings

Log in to the [Reduxi Configurator](#) (see [Point 3](#)), click **+ Add device** and enter the basic settings of the device.

4.2 Communication settings


Select the communication channel and enter the device configuration:

PARAMETER	VALUE
Unit address	Normally 1 is used

Then enter and choose the advanced settings.

4.3 Test communication

Click **Test communication** at the bottom of the wizard. It reads the Power-One solar inverter once and saves nothing. If the test succeeds, click **Done**: only **Done** creates the device.



The *Test communication* button

Text description of this image

Screenshot of the bottom button bar of a Reduxi Configurator page. Left: button 'Back'. Right: button 'Test communication' (marked with a cyan box) and dark button 'Done'.



The *Done* button

2. Text description of this image

5 Check the readings

5.1 Last measurements

After communication is established, check the values under **Devices** in the Reduxi Configurator as an additional test.

5.2 Strategies

To reduce energy costs with dynamic prices and dynamic tariffs, define a strategy as described in [Strategies for Reduxi controller](#).

✓ Summary

Preparation (Points 1–2): Open the manufacturer instructions. Connect and configure the inverter. Prepare the Reduxi Controller and a laptop or tablet.

Log in (Point 3): Log in to the Reduxi web interface of the controller.

Add to Reduxi (Point 4): Click + Add device, enter the basic settings, select the communication channel, enter the unit address (normally 1) and the advanced settings. Test the communication and press Done.

Go live (Point 5): Check the last measurements and define a strategy.

→ Common issues

ISSUE	SOLUTION
Unit address unknown	Normally 1 is used. Check the inverter settings in the manufacturer instructions.
Open configurator does not open or stays empty	The tunnel is not active yet. Wait about 30 seconds and check that the controller is online.
Login with admin is rejected	The password was changed during installation. Ask the installer. The Reduxi account password does not work here.
reduxi.local does not load	Your device is not in the same network as the controller. Use the IP address or the tunnel connection.
Communication test fails, device shows offline	Check reachability, IP address / port / unit ID, and that the protocol is enabled on the device.

→ Related articles

Matching guides from the Reduxi knowledge base:



Reduxi Configurator via the browser

How to log in to the Reduxi Configurator on the controller.



Device setup guides

All step-by-step guides for connecting devices to the Reduxi Controller



Strategies for the Reduxi Controller

Energy manager and other strategies explained